

Rhino Capra Axles & Rhino YUE ONE Chassis Assemble Guide


Rhino Capra Axles kit:



Step1 : Rear Link assembled:




Step2: Servo Mount assembled:



Step3: Riser Link assembled:

(If you assemble riser link only, please use M3*8mm screws, it put in riser bag)



If you assemble riser link and battery mount, please use M3*10mm screws, it put in battery mount bag



Step4: Gear box assembled:


Assemble 65-81mm driver shaft to Gear box



Step5: Please use curved link ends on 60mm length Titanium alloy Link:



Step6: Assemble 60mm length link and shock (95mm length) to front axles
(Use 2pcs M3*25mm screws)





Step7: Assemble 65-81mm driver shaft to front axles:



Step8: Assemble gear box to YUE ONE chassis




Step9: Assemble lower link to YUE ONE chassis



Step10: Assemble carrier to YUE ONE chassis





Step11: Assemble bent link and shock to Rear axlex

Use M3*25mm Screw





Step12: Assemble 190mm bent link to YUE ONE chassis

Use M3*20mm screw and d3-D6*5mm Spacer






Step13: Assemble 100mm length link to Rear link




Step14: Assemble 100mm length link to YUE ONE Chassis

Use M3*20mm screw and d3-D6*5mm Spacer




Step15: Assemble 101-154mm driver shaft:



Step16: Assemble shock to YUE ONE Chassis

Use M3*20mm screw and d3-D6*5mm Spacer



Step17: Assemble 55mm length link and Shock to YUE ONE Chassis

Use M3*15mm or M3*20mm screw and d3-D6*5mm Spacer

